

Premium Abdeckhaube BAH 100 für BBQ 4100/S



Wir freuen uns, dass Sie sich für diese hochwertige Grillabdeckung entschieden haben und bedanken uns für Ihr Vertrauen. Ihre neue Abdeckhaube ist ein Spitzenprodukt von erstklassiger Qualität. Damit Sie lange Freude an diesem Produkt haben, bitten wir Sie, die nachfolgenden Informationen sorgfältig zu lesen und zu beachten. Bewahren Sie diese Anleitung gut auf. Händigen Sie alle Unterlagen bei Weitergabe an Dritte ebenfalls mit aus. Vielen Dank.

Bestimmungsgemäßer Gebrauch

Dieses Produkt dient als Schutz vor Witterungseinflüssen und Verschmutzungen des Rommelsbacher BBQ 4100/S bei Nichtbenutzung. Es ist nicht für den gewerblichen Einsatz bestimmt.

Technische Daten

| | |
|---------------------|--|
| Material: | Oxford 600D (PU-beschichtet), ca. 230 g/m ² |
| Befestigungsbänder: | Klettverschluss, Material: PET und PA |
| Maße: | ca. 85 x 100 x 50 cm im Gebrauchszustand |
| Gewicht: | ca. 600 g |
| passend für: | BBQ 4100/S (mit deinstallierten Seitentischen) |

Lieferumfang

Kontrollieren Sie unmittelbar nach dem Auspacken den einwandfreien Produktzustand.

Für Ihre Sicherheit



- Abdeckhaube erst nach vollständiger Abkühlung des Grills aufbringen!
- Produkt nur für den vorgesehenen Zweck einsetzen!
- Kinder sollen beaufsichtigt werden, um sicherzustellen, dass sie nicht mit dem Produkt spielen. Erstickungsgefahr!

Reinigung und Pflege

- Abdeckhaube am besten mit warmem Wasser samt ein paar Tropfen handelsüblichem Geschirrspülmittel und Reinigungstuch säubern.
- Besonders gut eignen sich fussel- und kratzfreie Mikrofasertücher.
- Abdeckhaube keinesfalls mit einem Dampfreiniger behandeln.

ROMMELSBACHER

ROMMELSBACHER ElektroHausgeräte GmbH • Rudolf-Schmidt-Str. 18 • 91550 Dinkelsbühl
www.rommelsbacher.de

Premium grill cover BAH 100 for BBQ 4100/S



We are pleased you decided in favour of this superior barbecue cover and would like to thank you for your confidence. Your new cover is a top product of first-class quality. To make sure you can enjoy using this product for a long time, please read through and carefully observe the following information. Keep this instruction manual safely. Hand out all documents to third persons when passing on the device and its accessories. Thank you very much.

Intended use

This product protects the Rommelsbacher BBQ 4100/S from the weather and dirt when the grill is not in use. It is not suitable for commercial use.

Technical data

| | |
|----------------|---|
| Material: | Oxford 600D (PU-coated), ca. 230 g/m ² |
| Fixing straps: | velcro, made of PET and PA |
| Dimensions: | ca. 85 x 100 x 50 cm when in use |
| Weight: | ca. 600 g |
| Suitable for: | BBQ 4100/S (with side tables uninstalled) |

Scope of supply

Check the product for damage immediately after unpacking.

For your safety



- Only fit the cover once the barbecue has cooled down completely!
- Only use the product for its intended purpose!
- Children should be supervised to ensure that they do not play with the product. Risk of suffocation!

Cleaning and maintenance

- It is best to clean the cover with warm water, a few drops of standard washing-up liquid and a cleaning cloth.
- Lint-free and scratch-free microfibre cloths are particularly suitable.
- Never treat the cover with a steam cleaner.

ROMMELSBACHER

ROMMELSBACHER ElektroHausgeräte GmbH • Rudolf-Schmidt-Str. 18 • 91550 Dinkelsbühl
www.rommelsbacher.de