

Type: EBC 3075/E-15M
230V~ 3000W

*** ACHTUNG * * WICHTIGER HINWEIS ***

Dieses Modell ist mit einer **15-Minuten Zeitschaltuhr** ausgestattet. Um eine oder beide Heizplatten einzuschalten, wählen Sie zunächst mittels des zugehörigen Drehknebels die gewünschte Leistungsstufe aus. Danach drehen Sie den Knebel der Zeitschaltuhr im Uhrzeigersinn bis zum Anschlag und dann zurück bis zur gewünschten Einschaltdauer.

Die Zeitschaltuhr schaltet die Heizplatte automatisch nach Ablauf der eingestellten Zeit ab und ein kurzer Signalton ertönt. Sie können die Laufzeit jederzeit ändern, indem Sie den Knebel der Zeitschaltuhr nach links oder rechts drehen.

Stellen Sie die Drehknebel nach der automatischen Abschaltung immer auf „0“ Stellung.

*** ATTENTION * * IMPORTANT NOTE ***

This model is equipped with a **15 minutes timer**. For switching on one or both heating plates, first turn the respective rotary switch to set the desired power level. Then turn the timer switch clockwise as far as it will go and then back to the desired duration of use.

The timer switches off the heating plate automatically after the set time has elapsed and a short signal is audible. The operating time can be adjusted at any time by turning the timer knob to the left or right side.

Always turn back the rotary switches to their “0” position after the automatic switch-off.