

OMELETT CHEF

for hearty or sweet omelettes

Omelettes & more - no turning necessary



ROMMELSBACHER

With the practical Omelett Chef, you can prepare two juicy omelettes in no time at all. Whether for breakfast, brunch or the main meal – this unit also cuts a fine figure at the table. The two non-stick, extra-deep baking areas are also suitable for dough, so that, for example brownies or small tarts can be baked in this appliance as well. The baking areas are evenly heated from above and below. This results in a very even baking result and there is no need for turning the omelette while baking. This makes handling very comfortable and allows for other breakfast preparations. The Omelett Chef is operated via Soft-Touch buttons. A bright LED-display and two signal lamps provide best overview. A practical minute-by-minute cooking duration setting (1 to 20 minutes) with countdown function and signal tone reminds you when the desired baking time has expired. The Cool-Touch casing lives up to its name and - together with the anti-slip feet - offers a lot of safety in daily operation. The Omelett Chef is ideal for anyone who would like to quickly and easily prepare a hearty, protein-rich breakfast.



Ranking "very good" in
German consumer test



Technical data:

- type: **OM 950**
- 230 V~ 950 W • slate grey
- high-quality, heat insulated Cool-Touch casing
- extra-deep baking areas for preparing 2 fluffy omelettes at the same time
- 2 heating elements for an even heating from above and from below
- 20-minute timer with countdown function (residual time) and signal tone
- clear LED-display, Soft-Touch keys, 2 pilot lamps
- all round overflow gutter, for simple and clean filling and baking
- high-quality non-stick coating Xylan® Plus for easy and quick cleaning
- 4 non-slip rubber feet, integrated cord take-up